





IBL CRIMPER READY TO PLACE ON THE PANEL RIBS



IBL CRIMPER READY TO BE PLACED ON THE PANEL RIBS



IBL CRIMPER PLACED ON THE PANEL RIB



IBL CRIMPER PLACED ON THE PANEL RIBS

IBL CRIMPER READY TO BE PLACED ON THE PANEL RIBS

IBL CRIMPER CRIMPS THE RIBS



IBL ACTUATION CRIMPS PANEL RIBS TO 90°

IBL CRIMPER READY TO BE PLACED ON THE PANEL RIBS

IBL CRIMP PROFILE

